


GPS Mobile Navigation on the BenQ-Siemens EF81

Quick Start Guide

Please take note for the following points in order to successfully start using the GPS Navigation on your EF81:

1. Before connecting your external BT GPS receiver with your EF81, make sure to switch ON Bluetooth under Main Menu, Settings, Connectivity, Bluetooth®.
2. The EF81 only accepts BT connections with external BT devices that support BT PIN authorization. Make sure you are using a BT GPS receiver which offers PIN authorization (e.g. Fortuna Slim Bluetooth® GPS Receiver). GPS receiver can be acquired for a low price together with service registration (see 5).
3. For best audio volume experience when being routed by your Navigation, set your phones audio volume to Maximum under Main Menu, Settings, Ringtones, Volume. You can define a profile with Maximum volume and use this for navigation.
4. The navigation needs continuous positioning. Please pay attention that the GPS receiver is switched on, is charged, has free sight to the satellites, is paired with your phone and the time to get a first position is elapsed (can take a few minutes).
If the position fix is successful, the GPS-OK icon  appears or the red background field disappears.
Internet data communication in the mobile network is needed for the route and information requests. Therefore a suitable connection profile for your mobile network operator needs to be set in your telephone.
5. Registration information and support for the GPS Navigation Service is available at:
Internet: <http://www.vdodayton.com/mobilenavigation/>
Email: info-mobilenavigation@siemensvdo.com

BenQmobile

© BenQ Mobile GmbH & Co. OHG 2006
BenQ Corp. is a trademark licensee of Siemens AG